



RIGHT HAND DOOR OPENING (DIN LEFT)

With the hinges being visible, they remain on the left.



LEFT HAND DOOR OPENING (DIN RIGHT)

With the hinges being visible, they remain on the right.

